



**RECOMMENDED ADHESIVES FOR USE WITH HALO FLOORING – USE OF ANY OTHER ADHESIVES IS AT THE INSTALLER’S OWN RISK**

AAT – 420	(1.706.226.0610)	<a href="http://www.aatglue.com">www.aatglue.com</a>
	(Has to be used as a wet set).	
APAC – 560	(1.800.747 APAC)	<a href="http://www.apacadhesives.com">www.apacadhesives.com</a>
CHAPCO – SAFE SET 299	(1.800.621.0220)	<a href="http://www.chapco-adhesive.com">www.chapco-adhesive.com</a>
W W HENRY – 640	(1.800.232.4832)	<a href="http://www.wwhenry.com">www.wwhenry.com</a>
W W HENRY – 422	Available at Lowe’s	
MAPEI ECO 300	(1.800.426.2734)	<a href="http://www.mapei.com">www.mapei.com</a>
MAPEI G21		
MAPEI G19		
PARACHEM - M4619	(1.800.763.7272)	<a href="http://www.parabond.com">www.parabond.com</a>
W F TAYLOR – 2090	(1.886.818.7434)	<a href="http://www.wftaylor.com">www.wftaylor.com</a>
2091 for 5lbs moisture		
W F TAYLOR – 2092		
One part Epoxy		